




COMFORT CONTROL CENTER™

Part No. 3109228.001



This Comfort Control Center will provide your cooling and heating requirements regardless of your vehicle size.

USA
SERVICE OFFICE
The Dometic Corp.
509 So. Poplar St.
LaGrange, IN 46761
(219) 463-4858

CANADA
Dometic Dist.
866 Lings Dr.
Cambridge, Ontario
CANADA N3H 2N7
(519) 653-4390

**For Service Center
Assistance Call:**
800-544-4881


OPERATING INSTRUCTIONS

**Comfort
Control Center™**
Part No. 3109228.001

REVISION
Form No. 3108664.032 1/01
(Replaces 3108664.024)
(French 3109564.024)
©2001 The Dometic Corporation
LaGrange, IN 46761

Your recreational vehicle manufacturer has equipped your vehicle with Duo-Therm's Comfort Control Center™. The Comfort Control Center has been designed for you to easily operate all the air conditioning and gas heating appliances found in your vehicle from one location.

In order to familiarize yourself with the operation of the Comfort Control Center, the following diagram along with the accompanying text will explain all the functional characteristics of the system.



C. **FAN SPEEDS** – Possible available fan speeds are: **LOW, MEDIUM, HIGH** and **AUTO**. To select the desired fan speed, momentarily depress the **FAN** push button. You will need to continue to depress and release the **FAN** button until the desired fan speed is shown in the LCD readout area of the Comfort Control Center.

D. **TEMPERATURE SELECTOR BUTTONS** – The temperature Set-point range is from 40° to 99° Fahrenheit or 4° to 37° Celsius. Determination of Fahrenheit or Celsius standard is done at the time of your manufacturer's installation of the Climate Control Center. To set the temperature at your comfort level, simply depress and release the **UP** or **DOWN** push-button until the desired temperature is shown in the LCD readout area of the Comfort Control Center.

E. **ZONE SELECTOR BUTTON** – A **ZONE** is also established at the time of installation of your Comfort Control Center. If you have one air conditioner, you will have one **ZONE**. If your vehicle has more than one cooling system, depending on the manufacturing installation, you may have 2, 3 or 4 **ZONES**. Zones are defined and preset by your manufacturer. A zone is an area of cooling/heating which is controlled independently within that area, and regulated at the Comfort Control Center. A typical example of a two zone application would be a vehicle with two air conditioning systems, one in the front area (living room, kitchen) and one in the back section (bedroom and bath). The front area could be established as **ZONE 1** and the back section **ZONE 2**. You can select the desired temperature and fan speeds for each zone independently, thereby keeping your bedroom cooler than the front portion of the vehicle. To determine the number of established zones in your vehicle, depress the **ZONE** push-button. **ZONE 1** will be the first **ZONE** to appear in the LCD readout. The **ZONE** number selected will begin to flash and will flash for approximately 30 seconds or until another **ZONE** has been selected. Continue to depress and release the **ZONE** button until you see **ZONE 1** reappear.

F. **ON/OFF SWITCH** – The ON/OFF switch is located on the lower right hand edge of the Comfort Control Center. Move the lever from side to side to change status.

A. **LIQUID CRYSTAL DISPLAY** – Your Comfort Control Center is equipped with a liquid crystal display (LCD) that identifies the mode of operation, the temperature set-point, the zone identification and the fan speed. The Comfort Control Center is designed to accept and control many varied air conditioning and gas heating appliances. When you begin to first operate your Comfort Control Center, you will see that the LCD readout will only show the options available based on the appliances installed on your vehicle. An incandescent light will illuminate the LCD area when a selector button is pushed for easy reading at all times.

B. **MODE SELECTOR BUTTON** – Modes of operation available are: **OFF, FAN ONLY, COOL, HEAT PUMP, FURNACE, HEAT STRIP** and **AUX. HEAT**. Remember, your LCD readout will only show the options available based on the appliances installed on your vehicle. To select the mode of operation, momentarily depress the **MODE** push-button. You will need to continue to depress and release the button until the desired mode is shown in the LCD readout area on the Comfort Control Center.


To determine the Comfort Control Center options available to you, depress and release the **MODE** push-button until it goes through all selections.

OPERATING YOUR DUO-THERM COMFORT CONTROL CENTER

The Comfort Control Center allows you the freedom of controlling your vehicle's temperature to provide you with a comfortable environment to enjoy your life-style. With just a few simple steps, you can control which mode of operation you will use, the vehicle temperature and the fan speeds.

A. FAN ONLY MODE OF OPERATION

1. Begin by placing the power switch on the lower right hand edge of the Control Center on the **ON** position. To do this, simply move the lever to the right.
2. Momentarily depress and release the **MODE** push-button until the **FAN ONLY** indicator on the Liquid Crystal Display (LCD) is illuminated.
3. Momentarily depress and release the **FAN** push-button until the desired fan speed indicator (**LOW**, **MED**, **HIGH**, **AUTO**) is illuminated. If your vehicle is equipped with a heat pump or a dual basement air conditioning system, your selection choice will be **LOW**, **HIGH** or **AUTO**.
4. After approximately 5 seconds, the selected fan speed will come on. The **MODE** and **FAN** speed you have selected will remain shown in the LCD area of the Control Center until you change your selection.
5. If your vehicle contains more than one **ZONE**, depress the **ZONE** push-button to select **ZONE 2**, and repeat procedures from step two above. Repeat entire procedure for each additional zone.




B. COOLING MODE OPERATION

(To set cooling temperatures and fan speeds on Duo-Therm Air Conditioners & the cooling mode of Duo-Therm Heat Pumps)

1. Momentarily depress and release the **MODE** push-button until the **COOL** indicator on the LCD is illuminated.
2. Depress and release the **FAN** push-button to select your desired fan speed (**LOW**, **MEDIUM**, **HIGH** or **AUTO**). If your vehicle is equipped with a heat pump or a dual basement air conditioner system, your selection choice will be **LOW**, **HIGH** or **AUTO**.
3. Depress and release the **UP** push-button to increase the temperature or the **DOWN** push-button to decrease the desired temperature. The final selected **SET-POINT** will be displayed in the LCD area of the Comfort Control Center.
4. After a delay of approximately 2 minutes the air conditioner's compressor will come on and the cooling process will begin. Once the room temperature reaches the selected **SET-POINT**, the compressor will cycle off. Once the Comfort Control Center senses the need for cooling, the compressor will restart in approximately two minutes. At this point, the fan will either:
 - a. continue to operate in the single selected fan speed or,
 - b. cycle **OFF** and **ON** with the compressor if the **AUTO** fan speed has been selected.


5. If your vehicle contains more than one **ZONE**, depress the **ZONE** push-button to select **ZONE 2**, and repeat procedures from Step 1. Repeat entire procedure for each additional zone.



C. HEAT PUMP OPERATION

(To set heating temperatures for vehicles equipped with a Duo-Therm rooftop or basement heat pump. To operate cooling mode with a heat pump, see "B. Cooling Mode Operation", Page 3.)

1. Momentarily depress and release the **MODE** push-button until the **HEAT PUMP** indicator on the LCD is illuminated.
2. If you have not previously set your fan speed, you may do so by depressing and releasing the **FAN** push-button to select the desired fan speed.
3. Depress and release the **UP** push-button to increase the temperature or the **DOWN** push-button to decrease the desired temperature. The final selected **SET-POINT** will be displayed in the LCD area of the Comfort Control Center.
4. After a delay of approximately 2 minutes the heat pump's compressor will come on and the heating process will begin. Once the room temperature reaches the selected **SET-POINT**, the compressor will cycle off. Once the Comfort Control Center senses the need for heating, the compressor will restart in approximately two minutes. At this point, the fan will either:
 - a. continue to operate in the single selected fan speed or,
 - b. cycle **OFF** and **ON** with the compressor if the **AUTO** fan speed has been selected.
5. If your vehicle contains more than one **ZONE**, depress the **ZONE** push-button to select **ZONE 2**, and repeat procedures from Step 1 above. Repeat entire procedure for each additional zone.




NOTE:

See Page 7, Items F & G for additional Special Heat Pump Features.

D. FURNACE MODE OPERATION

(If your vehicle is equipped with a gas furnace connected to the Comfort Control Center)


1. Momentarily depress and release the **MODE** push-button until the **FURNACE** indicator on the LCD is illuminated.
2. The A/C fan does not operate in the **FURNACE** mode.
3. Depress and release the **UP** push-button to increase the temperature or the **DOWN** push-button to decrease the desired temperature. The final selected **SET-POINT** will be displayed in the LCD area of the Comfort Control Center.
4. Your Duo-Therm air conditioning system will not operate when the Comfort Control System is in the **FURNACE** mode. For cooling, change the **MODE** to **COOL**.
5. If your vehicle contains more than one **ZONE**, depress the **ZONE** push-button to select **ZONE 2**, and repeat procedures from Step 1 above. Repeat entire procedure for each additional zone.



E. HEAT STRIP MODE OPERATION

(For Duo-Therm air conditioners with an electric heat strip)

1. Momentarily depress and release the **MODE** push-button until the **HEAT STRIP** indicator on the LCD is illuminated.
2. The fan will operate in **LOW**, **MED** or **AUTO**. You will not be able to select **HIGH** speed when in the **HEAT STRIP** mode. Depress and release the **FAN** push-button to select desired speed. If your vehicle is equipped with a heat pump or a dual basement air conditioner system, your selection choice will be **LOW** and **AUTO**.
3. Depress and release the **UP** push-button to increase the temperature or the **DOWN** push-button to decrease the temperature. The final selected **SET-POINT** will be displayed in the LCD area of the Comfort Control Center.
4. The electric heat strip will cycle **ON** and **OFF** per the temperature **SET-POINT** displayed. The fan will either:
 - a. continue to operate in the selected fan speed or,
 - b. cycle **OFF** and **ON** with the heat strip if the **AUTO** fan speed has been selected.
5. If your vehicle contains more than one **ZONE**, depress the **ZONE** push-button to select **ZONE 2**, and repeat procedures from Step 1 above. Repeat entire procedure for each additional zone.



COMFORT CONTROL CENTER SPECIAL CONTROL FEATURES

A. AUTO FAN

When **AUTO FAN** is selected, the fan speed will be determined by the mode you are in.

1. **COOL MODE** – In the **COOL** mode, which is the air conditioning mode, the fan will automatically select the speed depending upon the difference between the temperature **SET-POINT** and the room temperature. When that difference is:

8° or more	The fan will operate on HIGH
4° to 8°	The fan will operate on MED
4° or below	The fan will operate on LOW
2. **COOL MODE (Heat Pump and Basement units)** – If your vehicle is equipped with a Duo-Therm Heat Pump or Basement unit, the fan will automatically select the fan speed depending upon the difference between the temperature **SET-POINT** and the room temperature.

When the difference is:	
8° or more	– The fan operates on HIGH
Less than 8°	– The fan operates on LOW
3. **HEAT PUMP MODE** – When **HEAT PUMP** mode is selected, the fan will start running in the **LOW** speed.

4. **HEAT STRIP MODE** – When **HEAT STRIP** mode is selected, the fan will start running in the **LOW** speed.

5. **FAN ONLY MODE** – In the **FAN ONLY** mode, the fan will start running in the **LOW** speed.

B. REFRIGERANT COMPRESSOR TIME DELAY

A time delay of approximately two minutes occurs any time the compressor is required to begin the cooling or heat pump cycle.

C. POWER INTERRUPTION


In the event that power to the air conditioner or control is interrupted, the system will restart with the same settings you have previously set.

D. ZONE CONTROL

Your Duo-Therm Control Center will operate cooling and heating appliances which your vehicle manufacturer has designed to heat or cool different areas (**ZONES**) of your RV. The Comfort Control Center will advise you if your vehicle has multiple **ZONES**, by showing **ZONE 1, 2 3** or

(D. Zone Control continued)


4 illuminated in the LCD readout. In the event your vehicle has multiple zones designed, you have the freedom of selecting the **MODE** of operation for each zone independently. To change from one zone to another, depress the **ZONE** push-button. Each time you depress and release this push-button, the indicator will change the zone data displayed. The zone number flashing indicates zone being programmed. The zone number will flash for approximately 30 seconds unless another zone is selected or programming has been completed. At this time the number will stop flashing and the display light will go out. When all zones have been programmed, the zones in operation will be underlined. To program each zone, simply repeat the programming steps shown in the operation section of this manual. Please note: The Comfort Control Center will prevent operating **FURNACE** and **COOL** or **FURNACE** and **HEAT PUMP** at the same time.



E. STAGE CONTROL OPERATION

If your vehicle is equipped with a Duo-Therm Dual Basement Air Conditioner or a Dual Basement Heat Pump, you have an air conditioning system that is designed to optimize comfort and running efficiencies. (Two units within one compartment). This is accomplished as long as the required electrical power is available, by providing an on-demand secondary stage of operation. (NOTE: The primary stage will continue to operate even if there isn't enough electrical power available to run the second stage.) The Comfort Control Center simplifies this operation and allows you to set the primary temperature set-point while the differential temperature set-point which activates the secondary stage is preset. After turning on your Comfort Control Center, perform the following steps to set and activate the stage control operation.

- 1) Momentarily depress the **ZONE** push-button to select stage in the zone desired
- 2) Momentarily depress the **MODE** push-button to select "ON".
- 3) Momentarily depress the **ZONE** push-button to select the zone where stage was selected in Step 1.
- 4) Momentarily depress the **MODE** push-button until the desired mode of operation is selected (**FAN ONLY**, **COOL** or **HEAT PUMP**).
- 5) Momentarily depress the **FAN** push-button until the desired fan speed is displayed (**LOW**, **HIGH** or **AUTO**).
- 6) Momentarily depress the **UP** and **DOWN** push-button until the desired room temperature set-point is displayed.




F. AUX. HEAT

When in the **HEAT PUMP** mode, if the outside ambient temperature is measured to be below 30°F and the vehicle is equipped with a furnace connected to the Comfort Control Center, the control will automatically select the **FURNACE** operation and the **HEAT PUMP** will shut down.


Important: If vehicle is not equipped with a furnace no heat will be available below 30°F. IF vehicle is equipped with a furnace and it is connected to its own thermostat, it must be manually turned ON and OFF for operation.

When this happens, the **AUX. HEAT** and the **HEAT PUMP** indicators on the LCD will illuminate. Once the outside ambient temperature is measured above 38°F, the control will return to the **HEAT PUMP** operation and shut down the furnace if it is connected to the Comfort Control Center. If furnace is not connected to the Comfort Control Center, the furnace thermostat must be manually turned off.



G. DEFROST CYCLE

This cycle is active during **HEAT PUMP** operation and allows the heat pump to operate down to 30°F. When the outside ambient temperature is less than 42°F and greater than 30°F, a defrost timing cycle will begin. The defrost timing cycle will allow operation of the heat pump for 25 minutes. The fan will then be shut off, the refrigerant flow reversed and run for 4-1/2 minutes, this is the **DEFROST** cycle. The refrigerant flow will then be returned to normal and, after a 30 second delay will continue until the temperature is greater than 42°F or until the temperature becomes less than 30°F, at which time the furnace will activate. (See **AUX. HEAT**). During the defrost cycle, the **DEFROST** indicator on the LCD shall be illuminated.




H. OPTIONAL AUTOMATIC GENERATOR START (AGS)

On vehicles equipped with an optional AGS kit the vehicle generator will automatically start when any zone calls for cooling and will shut off when all zones reach set point.

1. Put the power switch in the ON position.
2. Momentarily depress and release the ZONE push-button until AGS indicator appears on the LCD.
3. Momentarily depress and release the MODE push-button to select AGS status.

Important: When shore power is available, AGS must be switched to the off position.



GENERAL INFORMATION

- A. The ability of the air conditioner to maintain the desired inside temperature depends on the heat gain of the RV. Some preventative measures taken by the occupants of the RV can reduce the heat gain and improve the performance of the air conditioner. During extremely high outdoor temperatures, the heat gain of the vehicle may be reduced by:

1. Parking the RV in a shaded area.
2. Using window shades (blinds and/or curtains).
3. Keeping windows and doors shut or minimizing usage.
4. Avoiding the use of heat producing appliances.

Starting the air conditioner early in the morning and giving it a "head start" on the expected high outdoor ambient will greatly improve its ability to maintain the desired indoor temperature.

- B. The manufacturer of this air conditioner will not be

responsible for damage caused by condensed moisture on ceilings or other surfaces. Air contains moisture and this moisture tends to condense on cold surfaces. When air enters the RV, condensed moisture may appear on the ceiling, windows, metal parts, etc. The air conditioner removes this moisture from the air during normal operation. Keeping doors and windows closed when this air conditioner is in operation will minimize condensed moisture on cold surfaces.

- C. This equipment must be serviced by qualified personnel and some states require these people to be licensed.

MAINTENANCE

AIR FILTER: Periodically remove the return air filter. Wash the filter with soap and warm water; let dry and then reinstall or replace as required.

Note: Never run the air conditioner without the return air filter in place. This may plug the unit evaporator coil with dirt and may substantially affect the performance of the unit.

Comfort Control Center™: Clean the Comfort Control

Center™ with a moist, soft cloth. **DO NOT** use solvents for cleaning.

SERVICE

If your unit fails to operate or operates improperly, check the following before calling your service center.

- A. If your RV is connected to a motor generator, check to be sure the motor generator is running and producing power.
- B. If the RV is connected to a power supply by a land line, check to be sure the line is sized properly to run air conditioner load and it is plugged into the power supply.
- C. Check your 115VAC fuse or circuit breaker to see if it is open.
- D. Check your 12VDC fuse or circuit breaker to see if it is open.
- E. After the above checks, call your local service center for further help. This unit must be serviced by qualified service personnel only.

When calling for service, always give the following:

- A. Air Conditioner Model Number and Serial Number found on Rating Plate located on the Base Pan of the air conditioner.
- B. Electronic Control Kit Part Number and Serial Number found on Rating Plate located on the side of the Kit.

RETURN AIR GRILLE MUST BE REMOVED FROM THE RETURN AIR COVER TO VIEW THESE RATING PLATES.