

READ THESE INSTRUCTIONS CAREFULLY, KEEP FOR FUTURE REFERENCE.

Children and adults should be alerted to the hazards of high surface temperatures and should stay away to avoid burns or clothing ignition.

Young children should be carefully supervised when they are in the same room as the appli - ance.

Clothing or other flammable material should not be placed on or near the appliance.

Form No. 19-1075-2 11/79

FOR YOUR SAFETY

If you smell gas:

- 1. Open windows.
- 2. Don't touch electrical switches.
- 3. Extinguish any open flame.
- 4. Immediately call your gas supplier.

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this appliance.

Printed in U.S.A.