FOR YOUR SAFETY

It you smell gas: 1. Open windows.

2. Don't touch electrical switches. 3. Extinguish any open flame.
4. Immediately call your gas supplier.

ERVICE MANUALS

GAS/ELECTRIC REFRIGERATORS IM-40, IM-60, IM-70, and IM-90 Series







IMPORTANT

The installation must conform with the following American National Standards:

- 1. National Fuel and Gas Code: ANSI Z223.1-1974
- 2 Mobile Homes: A119.1-1975
- 3. Recreational Vehicles: A119 2-1975
- The unit must be electrically grounded in accordance with the National Electrical Code. ANSI C1-1975

In Canada, the appliance must be installed in accordance with:

- CSA Standard Z240.4 Gas Equipped Recreational Vehicles and Mobile Housing
- CSA Standard Z240 6.1 Electrical Requirements for Mobile Homes

OR

- 3. CSA Standard Z240 6.2 Electrical Requirements for Recreational Vehicles
- 4. Any applicable local codes and regulations



WARI IG:

Tampering with cooling unit will void warranty . . . UNLESS by an Instamatic Certified Cooling Unit Technician

CONTENTS HIGHLY FLAMMABLE AND TOXIC!

See page 47.

Table of Contents

Absorption Cooling Unit
Air Circulation 4
Analysis Tips 8
Diagram 2
Fill Valve 47
Refrigeration Cycle 1
Replacement
Things to Do Before
Returning
Types and Fart Numbers21
Burner
Changing:
Gas Line 23
Orifice 23
Thermocouple23
Drawings: Parts List 28, 32
Flue Assembly13
Pressure Measurement 20
Orifice Sizes
Odors11
Service Hints
Start-Up 9
Trouble-Shooting24
Cleaning
Cooling Unit
Before Returning;
"Things to Do" 47
Changing22
Identification
Trouble-Shooting 45, 46
_
Doors
Access Doors: #1422, #1422R
Changing Decorative Panel 14
Changing Swing 15, 16
Replacing Freezer Door 17
Travel Lock
Electric
Element Identification
and Wiring
Operation Analysis 46
Recommended Wire Gauges . 6 12 Volt Wiring Instructions 6
Thermostat: "Lost Charge" 11
Thermostat: "Lost Charge" 11 Wiring Diagrams 33-47
Trining Diagrams
Flue Assembly
Cleaning
Diagrams

Gas Trouble-Shooting24Burner PartsIdentification27, 32Ruby Orifice23
Heating Elements Schematics and Wiring 33-47 Specification Drawings 39-44
Innovator Refrigerator3Absorption System1Air Circulation4
Installation Instructions12Built-in Dimensions6. 712 Volt Wiring6Wiring Diagrams33-37Gas Connection5, 11, 28Installation Kits6, 7
Leveling 8
Maintenance
Operating Instructions 9
Operation Analysis (Gas)8, 45
Parts List
Pressure Measurement 20
ReplacingCooling Unit22Electric Selector Switch25Gas Line23Gas/Electric ControlAssembly25Heating Element38-42Lamp Cartridge29Lamp Switch26Orifice23Thermocouple23
Wiring Diagrams 33-47

When ordering parts, please refer to model number and serial number of refrigerator.


The second second

The Absorption System Cooling Unit

Absorption cooling units have many configurations (see page 21) but they all use the same working principle to transfer heat from one place to another.

The refrigerant, designated R 717 (ANSI B79.1-1968), is a solution of ammonia and water (NH₃ + H₂O). To enhance performance, an internal pressure of 20 to 25 atmospheres of hydrogen (H) is added.

Heat applied or removed at various points in the system (see Figure 1) causes a change of state (liquid to gas or gas to liquid) of the refrigerant, but unlike mechanical systems, there are no moving parts.



POINT 1 Generator-Boiler

Here a precise application of measured heat energy (either gas or electric) is applied. Refer to **Figure 1**, "Absorption Cooling Unit."

At point (A) a gas flame or at point (G) a resistance heat element causes the strong ammonia solution to boil. The rising ammonia vapor carries with it some weak ammonia solution through the system pump (percolator), point (B). The weak ammonia solution enters the smaller inner tube while the ammonia vapor enters the outer tube (D) where it passes down to point (E) through the strong liquid ammonia solution, picking up additional ammonia. It then rises through vapor tube (F) where remaining water runs back into the boiler and the dry ammonia vapor continues its rise to the system condenser.

POINT 2 Condenser

The system pressure at this point allows ammonia to condense at room temperature.

Here the condenser fins carry away some of the heat being transferred to the condenser tubes, thus lowering the temperature of the ammonia vapor enough to cause condensation.

The ammonia changes state (from vapor to liquid), and from this point (the high point of the system), gravity pulls the liquid ammonia (NH₃) down into the ammonia tube.

POINT 3 Evaporators

Pure liquid ammonia leaves the ammonia tube and spills into the low temperature evaporator (freezer box coil) where a large quantity of very light hydrogen gas creates an atmosphere around the pools of ammonia which permits the ammonia to boil off at low pressure and low temperatures. The more hydrogen and the less ammonia, the lower the temperature.


A portion of the liquid ammonia runs through the freezer box coil into the higher temperature evaporator (secondary) where it continues to boil at temperatures just below freezing. The heat required for this change of state (boil-off) is pulled away from the interior of the refrigerator and is carried away by the mixed ammonia-hydrogen vapor.

The mixed ammonia-hydrogen vapor, being heavier than hydrogen alone, settles downward to the absorber vessel.

POINT 4 The Absorber

As the ammonia-hydrogen vapor contacts the strong ammonia solution in the absorber, the ammonia goes into solution (is absorbed) and the very light hydrogen is freed to rise and return to the evaporators.

Heat liberated by absorbing the ammonia vapor is carried away by air passing over the outside of the absorber coils.



The Innovator Refrigerator

Electronic ignition, automatic burner re-light, a 12V interior lamp, increased storage capacity, standard width and depth dimensions, removable food bins, interchangable parts and components, service door servicability — all of these honor the name "Innovator"!

Home-like styling, color design coordination and advanced engineering techniques have been brought together to produce this modern, truly, functional refrigerator for a recreational vehicle owner or serviceman

Certifying agency standards have been faithfully kept in areas of safety and performance. Some of the new ideas built into the *Innovator* may well set future industry standards and some of the trouble shooting methods could be new to even the most experienced serviceman.

Considerable time can be saved by going through and becoming familiar with the trouble shooting techniques in this manual

A single thermostat and temperature sensing tube replaces the dual system used in most other refrigerators. The accuracy of this control, combined with a number of significant improvements in the burner, the cooling unit, and the cabinet, can maintain the relatively low temperatures to make ice or to safely store perishables.


The applied principles of physics (Dalton's, Boyle's, and Archimedes' Principles) give the Innovator the potential to be the best in the industry

Whether or not it meets its full potential is in the skilled hands of the installers and service techniciams.

The freezer compartment w normally maintain about 20° F (1 C) temperature below the average cabinet temperature when the ambient air is around 80° F (27° C

This temperature different increases or decreases normal with rise or fall of ambie temperatures

A careful study of the fit section of this manual ("Tabsorption System Cooling Unit will explain why.



Innovator Air Circulation

Figure 2 shows the cold heavier air around the secondary evaporator coil (Figure 1) falling, picking up heat from stored foods, then being warmed and rising again to be recooled.

Please refer to "Innovator Operating Instructions" and drawings for adjusting the temperature in this food storage area.

FIGURE 2 — AIR CIRCULATION

Innovator Installation Instructions

IN GENERAL

Set the *Innovator* into a wall cutout (see **Figs. 6** through **9** for proper dimensions). The *Innovator* **must be installed on a solid floor and secured** by running screws through holes provided in the rear support plate (from the service door) and through the holes provided in the cabinet molding

The method approved by certifying agencies for installation of the combustion air kit is shown for each model in Figures 6-9. Please note that the service door must be a #1422 rectangular door or a #1422R radius door (see Fig. 5). The roof vent must be a #620 (see Fig. 4). There are no alternate vents, doors, or installation methods. Therefore, deviations can cause agency field inspectors to red-tag now approved items

Since the *Innovator* uses an absorption cooling unit, proper air circulation over the cooling unit is necessary for satisfactory performance It is essential that the *Innovator* be installed so that air behind and above the cooling unit is unrestricted. The refrigerator cabinet must be enclosed at the bottom, sides, and top to eliminate pockets of air All joints in the enclosure must be sealed tightly to prevent products of combustion from entering the living area.

THIS ANSI 119.2 REQUIREMENT MUST BE MET

Spaces between the *Innovator* and the cut-in recess **must be positively sealed** by molding, gasket (foam) tape, or other suitable materials

ABOUT GAS CONNECTIONS

The gas inlet elbow permits the recommended 3/8" copper supply line to come from either the right or the left without bending the tubing The gas supply line must be free of sharp bends or kinks and should be installed so that it will not be damaged when the refrigerator is moved in or out of the recess.

LP GAS IS HIGHLY FLAMMABLE.

It is essential that all gas connections be tight and free of any leak.

Do not use a match to check for leaks.

This must be done in accordance with ANSI 119.2 standards or with a soap solution.

INSTALLATION PROCEDURE FOR INNOVATOR SERIES IM-40, IM-60, IM-70, AND IM-90

- 1 Cut recess opening to size of refrigerator shown in the appropriate installation diagram with approved zero clearance at sides, top, and back.
- 2 Install air vent kit supplied with refrigerator

See installation diagrams for dimensions and location

Vent kit must not be modified.

3 Make sure factory installed gasket tape (polyether or equal), 1/4" x 3/8", is in place and unbroken on the back side of the refrigerator cabinet molding, control box assembly and top cap assembly to assure combustion chamber is isolated from vehicle interior.

THIS IS AN ANSI 119.2 REQUIREMENT

- 4 Inspect flue pipe for any foreign materials (spider webs, packing materials, etc.)
- 5 Set *Innovator* in cut-out and secure to vehicle by inserting wood type screws through predrilled holes in rear support plate from the service door opening and through the holes provided in the refrigerator cabinet molding into the recess opening studs
- 6. Connect gas supply, 3/8" copper tubing, to 3/8" male fitting on refrigerator After installation, gas should be turned on. USE LP GAS ONLY (11" water column manifold pressure). All joints should be checked for gas leaks up to the burner according to ANSI 1192 standards or with a solution of soap and water Do not use open flame to test for gas leaks Occasionally connections become loose during shipment or from vibration while in transit and this method of testing with soap should be done periodically on all the gas fittings If gas leak is found, turn off gas supply at tank and have problem corrected at nearest service center. The owner must not attempt to "fix" any gas leak.

USE LP GAS ONLY.
Check for leaks using
ANSI 1192 standards or
soap and water solution only.

All Innovators are factory tested for use on HD5 propane ONLY!

7 Connect 115 volt power using prong plug supplied by Instamatic in vehicle 115 volt receptacle.

NOTE: the following tag supplied by Instamatic must be left on all refrigerator 115 volt power cords.

WARNING

Electrical Grounding Instructions

This appliance is equipped with a three prong (grounding) plug for it is protection against shock haza: should be plugged d.v. !!y into noperly grounded e proverly grounded e provinces

DO NOT CUT OR REMOVE THE GROUNDING PRONG FROM THIS PLUG!

8 Connect 12 volt power to terminiblock on unit back 2-way refrigerators require only a #18 AWi hook-up to the battery for the igniter and interior lamp circuits 3-way refrigerators require a #1 AWG hook-up to handle the 1 volt heating element. See "12 Vo Wiring" for details

NOTE: Any work involving gas piping, lossed gas litting, arrived or ruptured gas lines set... must be done by the RV manufacturer or by an authorized sorvice center or dealer. If you need that something is whoma with the gas pressure or the gas installation, go to your authorized service dealer.


The customer must never. never attempt any job that involves the loosening of ANY gas connection.

9. After putting the *Innovator* int operation, allow several hours be fore checking the cabinet temperature. Cooling time will vary wit conditions (outside and insidemperature, humidity, exposur to direct sun, etc.). Wheneve possible, the service door side the RV should be shaded fror direct sun exposure to enhanc *Innovator* performance

12 VOLT WIRING

For the 12 volt element in a 3-way Innovator, the installer must run wire heavy enough to handle the amp draw shown on the rating plate. A mimimum #10 AWG stranded copper with 1/32" (30 mils rated at minimum 60° C) thermoplastic insulation (type MTW or equivalent) is necessary. Unless this high amp circuit runs through the vehicle ignition, an automatic cut-out relay must be installed to prevent power drainage from the vehicle battery when the engine is not running A 25 amp in-line fuse is provided. If an RV fuse panel is also used, a 30 amp fuse should be installed in the panel, even though current should seldom exceed 21 amps.

A separate 12 volt internal circuit provided for the interior lamp and automatic igniter in the Innovator 3-way refrigerator. This circuit is marked on the 4-terminal block of the 3-way and is the only 12 volt circuit (2-terminal block) on the 2-way



Innovator. Use a minimum #18 AWG supply wire for this low amp circuit (less than 1 amp) which may be fused but need not be run through the vehicle ignition nor an automatic cut-out relay.

NOTE: Do not try to operate refrigerator from a battery charger.

The output from a


The output from a battery charger will not be sufficient for good operation.


NOTE: Before attempting any service on the refrigerator, be sure to **disconnect** both the 12 volt leads and the 115 volt plug.

Battery circuits furnished and installed by the recreational vehicle manufacturer and not part of the automobile ignition circuit do not require a cut-out relay. An overcurrent protective device (circuit breaker or fuse) must be provided however.

IM-42 — Use 18 guage wire	IM-72 — Use 18 guage wire
IM-43 — Use 10 guage wire	IM-73 — Use 10 guage wire
IM-62 — Use 18 guage wire	IM-92 — Use 18 guage wire
IM-63 — Use 10 guage wire	IM-93 — Use 10 guage wire

Minimum Built-in Dimensions






Why Leveling?

Your new *Innovator* absorption refrigerator is powered by an LP gas flame or an electric heat element, permitting you to have silent refrigeration wherever you go. In order for this to be possible and practical, certain conditions must be met.

Cooling unit refrigerant uses heat and gravity as a source of circulating power. The heat generated by either gas flame or electricity circulates the refrigerant in the form of a vapor up through the condenser where it is changed to a liquid. From this point, it flows down through the freezing zone (of freezing plate) on its way back to the generator, completing the cycle.

When the liquid ammonia passes through the freezing plate it is again changed into a vapor by heat absorbed from the food and cabinet area. If the heat laden vapor is trapped or partially trapped by



liquid ammonia, preventing it from passing out of the evaporator (or freezing plate) due to an unlevel condition, the results will be a total or partial loss of refrigeration. For this reason, TAKE A LITTLE TIME TO LEVEL the freezing plate, using a small bubble level (see Fig. 10) and adjust the RV so that this point (center of freezer plate) is level side to side and front to back.

The refrigerator is normally installed with the freezing plate level in relation to the floor (center) of RV; if you find this true, then level the RV floor; if not, level from the plate.

IN-TRANSIT OPERATION

While the *Innovator* must be level when the RV is parked, it will perform under temporarily off-level conditions in transit.

When the RV is moving, a washing action caused by the motion will prevent any liquid from trapping this vapor on its way back to the generator for recirculation. In addition, traveling creates more air circulation for the air cooled unit, resulting in improved performance.

Tips on Cooling Unit Analysis

Your *Innovator* has been engineered to give long, trouble-free duty. It is therefore obviously important that all external factors affecting performance be checked thoroughly before any part is condemned as faulty — especially the cooling unit.

Emphasis has been placed on good and proper installation and leveling Just as important are things like correct heat input, clean flue tube and clean and unrestricted top cap and service door louvers All Innovators carry the wattage rating and gas BTU input for each unit. Note: gas pressure must be 11" w.c.—higher or lower gas pressure will change performance on gas Wattage is based on 115 volts plus or minus 5%. Greater variations in voltage will affect performance on electricity The ruby gas orifice is laser drilled to give an infinitely smoother bore which won't pick up the dirt common to a drilled brass orifice. Any attempt to enlarge the ruby orifice will crack the ruby and make replacement necessary As a rule, the ruby orifice should never need changing unless it has been abused

—and the size should never be changed with the idea of enhancing performance.

Make certain electrical element(s) are inserted to the bottom of the well or to the stop provided on some brands of elements. Improper positioning, like improper gas input, will cause improper vaporization of ammonia in the boiler. Ultimately this may cause the liquid mixture in the boiler to become weak, resulting in the system pump malfunctioning. When the circulation of liquid ammonia slows or stops it may seem that the cooling unit is defective; when in fact the culprit may be one or more of the above. If the vapor pipe from the boiler to the condenser becomes very hot (sometimes the paint will blister or metal will be discolored) the serviceman can be sure of a system blockage - probably caused by improper heat, operating in an off-level position, inadequate ventilation or direct sun in very high ambients.

Good and proper analysis takes time, but it may well save time and money in the long run. The *Innovator* should be run a minimum of

eight to twelve hours at the "coldest" thermostat setting prior to examination by the serviceman. This can be arranged by telephone when the service appointment is set up or when the service order is written for "drive in" customers. After the Innovator has been operating for about eight hours, the cooling unit should stabilize The absorber coil should be warmer at the bottom than at the top. The absorber vessel will be slightly warmer. The vapor pipe from the boiler to the condenser will be hot, but bearable to the hand where it joins the condenser, becoming hotter as it moves toward the boiler

Summary- before condemning a cooling unit:

- 1. Check wattrace or gas input signature plate.
- 2. Check for proper electrical clement position?
- 3 Check gas flame characteristics (sharp blue).
 - 4. Check flue for spider webs, carbon, obstructions.
- 5. Check service door and roof vent for blockage

Innovator Operating Instructions

LEVEL

After the RV is parked, make sure your *Innovator* is level (see page 8), "Why Leveling?" for explanation) Use the small bubble level provided for this purpose (Fig. 11).

SHADE

A good rule for best *Innovator* performance. park your RV so the *Innovator* service and vent areas are shaded from direct afternoon sun Excessive solar load can have an adverse effect on performance

CONTROLS

A 2-way Innovator has two control knobs and a 3-way has three knobs Located behind a sliding door at the base of the Innovator, all controls are accessible without opening the refrigerator door A single thermostat knob regulates temperatures for either gas or electric operation by turning clockwise 330° from defrost to coldest setting. Factory calibration gives 3° to 5° differential between on or off on electricity and full on or bypass on gas.

The gas/electric control knob just to the right of the thermostat rotates 90° each way from the horizontal (off) position. **Depress** and turn 90° clockwise for electric operation. **Depress** and turn 90° counterclockwise for gas operation

On 3-way *Innovators*, a rotary selector knob must be set at either 12V or 115V.

The flame meter replaces peep holes, prisms, etc. to indicate a flame has been established by the automatic igniter during gas operation.

START UP

Gas Operation

- 1 Make certain 12V power is available at terminal block for electronic ignition and interior lamp.
- 2 Turn on gas supply at tank
- 3. Depress and turn gas/electric control 90° counter-clockwise to "gas" position
- 4. Hold in depressed position until flame meter needle moves into green area.
- 5. "Ticking" of automatic igniter should stop. Release knob.

NOTE: Air in the lines may cause flame to extinguish long enough to break magnetic safety—repeat steps 2, 3, and 4

Turn thermostat clockwise to coldest position for the first few hours of operation.

Electric Operation

- Make certain power is available through 115V power cord and the 12V wires to the terminal block on back of *Innovator*.
- 2 For 3-way *Innovators*, set 12V/ 115V selector in proper mode
- Depress gas/electric selector switch and turn 90° clockwise to electric position
- Turn thermostat clockwise to coldest position for the first few hours of operation

IMPORTANT RECOMMENDATION 12 volt operation should be used only in transit

Before leaving home, plug in RV utility cord and operate Innovator on 115 volts (or LP gas if preferred) about 8 to 12 hours. The unit will be cold and may then be switched to 12 volt operation for highway use.

At destination, *Innovator* may be switched back to 115 olts or LP gas.

OPERATIONAL SWITCHING

To change from 12V to 115V to gas operation, use the same pedures outlined under "Start I Make certain all controls are set the proper position and that power connections are made, power must be available to the amatic igniter and lamp circuits wiring diagrams, pages 33 thro 37 for gas operation and pag "12 Volt Wiring" for complete structions).

ICE MAKING

Rapid ice cube production is a sible when the thermostat is in coldest position (full clockwise). Because of the time norm required for ice making, an an supply of ice cubes should be sto in the trays ready for immediate if frozen foods are to be stored in freezer compartment, thermomay be kept at or near the cole position

Freezing of foods stored near back of the upper shelves below freezer will require turning thermostat to a slightly war (counter-clockwise) position.

DEFROSTING

Never use a hair dryer or oth heat-producing appliance hasten defrosting. Filling the ic cube trays with hot water w minimize defrost time and prevent heat build-up in store perishables.

Defrost at regular interva whenever heavy frost build-up noted. Thermostat should be in "defrost" (full counter-clockw position. As soon as front mixing all moisture from freezer interior parts and turn thermosti "coldest" (full clockwise) posit Careful attention to this simmaintenance procedure enhar Innovator efficiency.

Refrigerator Care and Maintenence

CLEANING

The best time to clean the cabinet interior is while the *Innovator* is defrosting. After removing all stored foods, wash with lukewarm water to which a small quantity of mild household detergent has been added.

Never place removable components in a dishwasher and never use abrasives, steel wool, or scouring powder.

Rinsing in a solution of baking soda and water will freshen up areas which have had food spills. Wipe with a soft dry cloth to minimize water spotting

Regular attention to this normal household chore will assure the fresh taste of stored foods and can minimize food stains on interior components

When Innovator is NOT in use, it is recommended that the interior be cleaned and that the door be left open until all components are dry in order to prevent growth of odorcausing bacteria

STORING FOOD

- 1 Proper refrigeration requires free air circulation within the food storage compartment Restricted air circulation within the food storage compartment will cause higher cabinet temperatures Rearrange foods (Fig. 2, page 4)
- 2 It is also essential that the shelves are *not* covered with paper or large storage containers
- 3 Odorous foods or highly flavored foods should *always* be stored in covered dishes, plastic bags or wrapped in foil or waxed paper to prevent food odors. Vegetables, lettuce, etc., should be covered to retain their crispness. **Never put hot food into the refrigerator.**
- 4 To reduce frost formation in and on the freezing compartment, cover stored liquids and moist foods and do not leave the door open longer than necessary
- 5 When the refrigerator is heavily loaded, it takes longer for refrigerator temperatures to lower, requiring a much longer time for ice-making. A very heavy load may also cause unplanned defrosting.

ICE CUBES

Do not use warm water. Faster freezing will result if precooled water is used

TRAVEL LOCK

The travel lock **must be** fitted to hold the door closed while in transit.

GASKET SEALS

1 For correct operation, it is essential that the door gasket makes a good seal all around, against the front of the cabinet

The compression of the gasket, down the hinge side, must not be too great. The gasket should just contact the front of the cabinet when the door is closed. This is normally allowed for during manufacturing.

Failure of the door gasket to contact the front of the cabinet may be determined visually when the door is closed Run a "dollar bill" along the door seal, inserted between the seal and the cabinet front Nowhere should the bill feel loose Replace gasket if necessary

- 2 Innovator has integral door alignment, making a good door seal more positive Positioning hinge fixing screws has been eliminated
- 3 It is also essential to make certain that the cabinet opening through which the evaporators enter the cabinet are properly sealed by a gasket or sealing compound. If these seals leak, warm air enters the cabinet, causing high cabinet temperatures and excessive frost formation in the freezing compartment.

FLUE OBSTRUCTIONS

On gas operation, the flue normally requires occasional cleaning. To do this it will be necessary to gain access to the back of the cabinet. When cleaning the flue, proceed as follows.

Completely remove refrigerator Then remove burner box and cover the entire burner assembly with a piece of foil and lift out the baffle on its support wire from the top of the boiler tube. From the top, clean the flue with a suitable flue brush. Clean baffle before replacing

NOTE: Some cooling units DO NOT use a metal twist baffle

An obstruction in the flue will reduce or stop flue draft Flue obstructions will cause odors outside the refrigerator, slow freezing and higher cabinet temperatures. Flue blockage may also cause the flame to burn outside the flue tube. Refer to "Odors from Fumes."

ODORS INSIDE THE REFRIGERATOR

Odors inside the refrigerator are caused by improper food storage See "Storing Food" (page 10) Odors may also be caused by too infrequent cleaning of the food compartment or from the refrigerator being shut off for some time with the door closed

ODORS FROM FUMES

1. Odors outside the refrigerator may be caused by gas leaks Make sure that all shut-off valves on all gas appliances are closed Test gas connections and all joints in the gas line with soap and water solution

Never look for a leak the with an open flame.

Use a tlasnlight when necessary in looking for soap bubbles caused by leaks. The gas line should be free of kinks and sharp bends. Turn on gas valve, light burner and test connections.

between the gas valve and the burner carefully with soap and water.

- 2 Odors outside the refrigerator may be caused by improper burner flame
- 3 Flame touches side of the boiler due to dislocation of the burner Relocate. Burner dislocation may also cause smoking, and sooting
- 4 Burner damaged Replace.
- 5 Flame touches the flue baffle Correct position of baffle.
- 6 Flue tube is dirty Clean the flue.

LOST THERMOSTAT CHARGE

Sometimes the electric control switch may appear to be faulty the thermostat sensing tube is filled with inert gas. When the tube is ruptured, the thermostat loses its charge and will become inactive If the charge is lost, the burner flame will remain on minimum or the unit will not perform on electricity regardless of the control knob position! Proceed as follows for the test After removing the sensing tube from tube retainer in the evaporator, warm up the tip (approximately 3") of the capillary tube by holding it with fingers. If the flame fails to enlarge or, the electric heating element fails to operate, the thermostat has lost its charge

AND the entire Sourdillon Control MUST BE REPLACED! See page 25.

SERVICE HINTS FOR BURNER

If the burner flame extinguishes when the thermostat is set to reduce the flame to a very low or by-pass flame.

1 The tip of the thermocouple is located too far away from the flame Check mounting screws of the burner bracket; make corrections, or replace with a new one 2 The connection between thermocouple and the continot tight enough For coconnection, a torque ran from 20 to 25 inch/pount recommended See page 23

IMPORTANT: The ups of the rm or surple and it goitton tip must be set point at the burner head.

In case the attempt at burne nition has to be repeated becaulighting failures:

- 1 See Start-Up, page 9
- 2 See Innovator Trouble-Sho Chart, page 24

IMPORTANT: The ties of the emocouple, and it automatic ignition device factory set at the same leand point to the top of burner head Field adjument will almost never necessary.

BURNER ORIFICE CLOGGED

Should the ruby burner c become clogged, the flame decrease on the maximum sett the thermostat and will affec burner heating output and resi decrease of cooling efficiency

REPLACE RUBY ORIFI hard ≥ 23. Never attempt to clube ruby orifice with a wire-device which will crack ruby.

BURNER ORIFICE

The ruby orifice size is designed by the number stamped on the of the orifice as follows

Model	Orifice
IM-40 Series	32
IM-60 Series	37
IM-70 Series	37
IM-90 Series	415

CONTRACTOR CONTRACTOR SOUTH AND A LOCAL CONTRACTOR OF THE SOUTH CONTRACTOR OF

11

Should an orifice of a different size be substituted, cooling efficiency will be affected and may cause cooling unit failure, and will yold the cooling unit warranty.

The ruby orifice is laser-drilled and CANNOT be modified or changed. Use of any wire-like device to clean or enlarge the orifice will result in breaking the ruby.

General Maintenance Instructions

TROUBLE SHOOTING

If your refrigerator is not working properly, check the **Trouble-Shooting** hints listed on pages 24, 45, and 46

If your refrigerator still fails to operate, turn it off at the on/off knob and electric on/off switch and contact Instamatic immediately, giving the model number and the serial number shown on the name-plate and complete details of your troubles Try to diagnose the problem and avoid the word "defective."

IMPORTANT:

Repair of the *Innovator* refrigerator must be performed by an authorized service point or selling dealer.

Tampering with any part of the refrigerator by unauthorized personnel will automatically void the warranty.

FLUE CLEANING

An obstruction in the flue will reduce flue draft and can result in higher cabinet temperatures and faulty operation. It is advisable to clean the flue at least once each year so that it will be kept free of dust, spider webs, and soot.

It will be necessary to gain complete access to the back of the cooling unit by pulling the *Innovator* from the RV Proceed as follows

Remove the metal burner housing and cover the burner assembly with a rag so that loose dirt will not fall into the burner Remove the flue baffle* by lifting on the baffle support wire until it is out of the flue tube. From the top, clean the flue with a suitable wire brush. Clean the baffle before replacing.

The refrigerator must be inspected periodically and before reuse after shut-down

 Check all gas connections for possible leaks using a solution or soap and water

(Do not use a lighted mater.)

- 2 Inspect the flame for color. It should have a sharp blue cone and mantle—NOT YELLOW Check for a high and low flame. This can only be observed after several hours of operation
- Check the interior of the flue tube for possible soot deposits Remove flue extension tube by removing bracket and removing the flue baffle. Clean inside of flue tube with a wire brush and reassemble parts.

^{*} Some cooling units do not have an internal baffle.

Flue **Assembly**

The dimensions of the flue and the flue baffle have been engineered to give best possible efficiency and meet A.G.A and CSA standards


The baffle distributes the heat produced by the burner and enhances the draft, providing primary and secondary air to the burner.

The sizes and distances differ with each cooling unit It is important that these factory dimensions be maintained to insure proper performance and safety

Burner must be perfectly aligned so that flame never impinges on any part of the flue tube or burner box

assembly

FLUE TUBE



BURNER

Changing Decorative Panel

As easy as





FIGURE 12 — THE EASY 1-2-3 WAY TO CHANGE YOUR DECORATIVE PANEL

Lift bottom of trim strip slightly away from panel.



Pull trim strip down and away.

3


Slide out old panel; slide in new panel.

INNOVATOR DOOR PANEL SIZES

Model	Wood Panel*	Metal Panel†
IM-40	26¼ x 24½	26½ x 24¾
IM-60	35¼ x 24½	35½ x 24¾
IM-70 Freezer	9½ x 24½	9¾ x 24¾
IM-70 Lower	35¼ x 24½	35½ x 24¾
IM-90 Freezer	1 /2 x 24½	13¾ x 24¾
IM-90 Lower	351/4 x 241/2	35½ x 24¾

- * Wood panel is 5/32" plywood.
- † Decorative metal requires 1/4" foam tape strips on back.

NOTE: All tolerances ± 1/16"





Changing Door Swing From Left To Right

The door hinges on the Innovator have been designed to permit opening either to the right or left.

To change the door swing:

- 1. Remove end cap holding scre (Figure 13). Part number A4-320022-011. (If your Innovator has screws remove them!)
- 2 Remove both top end caps






IM-70 OR IM-90:

Lift off freezer door from center hinge on IM-70 or IM-90. Unscrew center hinge pin, lift off lower door. See step 6 to reinstall lower door. Replace center hinge pin to secure lower door.

- 5. Pop out travel lock and reinstall on opposite side.
- 6. Unscrew lower hinge. Pop out plastic plug and reinstall on opposite side.
- 7. Set door on lower hinge and reinstall top hinge pin to hold the door in place.
- 8. Replace both top end caps.
- 9. Replace end cap holding screws.



Replacement of Freezer Door on the IM-40 and IM-60

- 1 Push carrier ("A") inward by means of a blunt mandrel or pin (Fig. A) and remove the shutter.
- 2 Pry the spring housings ("B" in **Fig. A)** away from the lining so that it snaps out and turn the spring housings down 180° (**Fig. B)**.
- Mount the new shutter in close position first on one side, making sure that the cross slots engage in the cross on the hinge plate ("C" in Fig. A).
- 4 Press the carrier on the opposite side so that the hinge plate on the shutter can be pushed over it. See that the crosses engage.
- 5 Turn the spring housings round and up until the small tag ("A" in Fig. B) snaps into the slot in the lining

NOTE: Illustration is for right hand hinge—both left hand and right hand assemblies are used




FIGURE A






FIGURE B

- 1. Vegetable Tray Large*
- 2 Thermostat Control Knob
- 3ই Gas Electric Selector
- 4. Flame Meter
- 5 12V 115V Electrical Control (
- 6. Control Cover
- 7. R. H. End Cap (Bottom)
- 8 Hinge Pin (Bottom)
- 9 Mounting Screw (Side Molding to Cut-Out Surface)
- 10 L. H. End Cap (Top)
- 11. Lamp Assembly
- 12: Hunge Pin (Top)
- 13: 🛣 H. End Cap (Top
- 14 Mounting Screw (Bear Support Flate to Floor)
- 15. Hear Support Plate
- 16. Plustic Plug
- 17. Travel Latch
- 18. Butter Box Assembly
- 19. Egg Tray (2)
- 20. Small Door Shelf
- 21. Bottom Door Shelf
- 22. Door Trim and Decal
- 23. Vegetable Tray Smark
- 24. Bubble Level

*Optional items on some linnovators





Pressure Measuring Devices

WATER "U" GAUGE

The water gauge consists of a glass "U" tube filled with water up to the mid-point. When gas pressure is exerted on one side of the gauge, the water on that side is forced down and there is a corresponding rise of water on the other side (Fig. 15).


Water column pressure is indicated by the difference of the two columns of water measured in inches.

A convenient scale reading in inches and tenths of an inch is mounted between the two columns

When reading the gauge, proceed as follows:

Fill the gauge with water up to the zero level. Connect the hose to the pressure testing outlet. Normal working pressure may force the water column to go down to 55 inches below the zero level, whereas the other column rises up to 5.5 inches above the point zero or midpoint Adding the two will result in a water column of 5.5 + 5.5 = 11 inches.

For measurement accuracy, a water "U" gauge is far superior to a low pressure gauge If a low pressure gauge is used, it should be checked for accuracy against a water "U" gauge occasionally






FIGURE 16 — LOW PRESSURE GAUGE (Fisher)

(FISHER) LOW PRESSURE GAUGE


This gauge is calibrated to read in "inches of water column pressure" It is a standard manometer reading and is colored red.

HOW TO USE THE PRESSURE GAUGE


Fig. 16 shows the Fisher low pressure gauge. When testing the pressure to the burner, tee into the supply line from the gas bottle (such as a gas range pressure tap as shown in Fig. 17). Then connect the hose from the pressure gauge. It is very important that the gas operated refrigerators operate at correct pressure; i.e., at the pressure specified for the refrigerator.

The pressure of the burner should be checked at the time the refrigerator is started up. After connecting the pressure guage, set the thermostat dial at "COLDEST." Turn on the gas and light the burner.


At the "COLDEST" setting the pressure reading should be at a minimum of 10½" or a maximum of 11½" if the L.P. gas is supplied directly to the refrigerator from the regulator fitted on the gas bottle at pressure of 11".




IM-40 C (TH) Part #4-330-924




IM-60 C (TH) Part #3-330-107




IM-60 S



IM-70 C / IM-90 C



M-90 CF





Replacing a Cooling Unit

- With the refrigerator in the upright position, remove the mounting screws in freezer box and cut the 12V interior lamp wires behind the spade connectors.
- 2. Remove the protective grill from refrigerator cooling coil.
- 3. Loosen capillary tube from the retainer (Fig. 19) by backing the Phillips-head screws in the plate retainer out about two turns Straighten the capillary tubes, being careful nottocrimporbreak them Pull tubes out from back of cabinet. Carefully coil to prevent kinks or breaks.
- 4. Lay the refrigerator face down. Remove the two Phillips-head screws holding the burner box cover and slide the cover off (toward the bottom of the refrigerator). Remove both machine bolts holding the box to the bottom of the cooling unit (Fig. 21).
- Pull the electrical spade connectors apart in the insulating sleeve to free the electrical heating element.
- Remove all self-tapping metal screws holding the cooling unit to the cabinet of the refrigerator.
- Lift the cooling unit from the refrigerator cabinet. Because of the weight and the hydraulic action of the thermal mastic, this is often a job for two people.
- 8. Remove the plastic inner lid (if your unit has one) from behind the secondary evaporator and install on the replacement unit. If liquid adhesive is available, spraying the plate lightly will provide a good seal to the new unit.
- Perfect freezer box contact is essential. Therefore, use all of the thermal mastic supplied with the replacement cooling unit

NOTICE:


Because a cooling unit is a delicate instrument and a major component which sometimes sustains rough handling in shipment, it is recommended that any replacement cooling unit be hung level on the wall and operated on the electric element about eight hours prior to installation on a refrigerator. Such a "run-in" assures the quality of the replacement cooling unit.





EVAPORATOR RETAINER

FIGURE 19 - TYPES OF CAPILLARY TUBE RETAINERS



22


How to Change an Orifice

- 1 Hold the orifice with a 12 mm. open end wrench and disconnect the gas line flair nut with a 13 mm. wrench Be careful! Any sharp bends in the aluminum gas line will result in leaks and necessitate its replacement
- 2. Back the orifice out of the burner with a 12 mm, wrench.
- 3. Thread the new orifice into the burner and tighten securely
- 4. Carefully reposition the gas line and thread the 13 mm. flair nut onto the orifice. Make sure that the gas line is in a straight line with the burner, and, while holding the orifice in place with a wrench, tighten the flair nut firmly.

NOTE

Whenever making any repairs involving gas connections, always check for leaks when repairs are completed.

Any attempt to clean a ruby orifice with a wire-like device will crack the ruby and result in extreme malfunction!



How to Change a Thermocouple


- Removal of the burner box cover will make access to the thermocouple retaining clip easier. Remove the two Phillips-head screws which hold the cover in place and slide it back and then out.
- Remove the igniter electrodethermocouple retaining clip by removing the screw and pulling the igniter electrode and thermocouple out of the burner
- 3. Remove the blue flame meter wire from the thermocouple terminal
- 4. Carefully remove the 5/16" nut from the back of the gas control and remove the thermocouple.
- Replace the new thermocouple in the burner along with the igniter electrode and replace the retaining clip
- 6. Thread the 5/16" nut back into the control.

Carefully torque this nut down to 20-25 inch/pounds

- 7. Replace the blue flame meter wire into the thermocouple interrupter (terminal) and tape if necessary
- 8. Replace the burner box cover (*if* you removed it).

How to Change a Gas Line

- Holding the orifice with a 12 mm wrench, loosen the 13 mm. flat nut.
- Hold the 11 mm fitting next to the gas control (or pressure tap) and loosen the 13 mm flair nut Be careful not to rotate the pressure tap.
- Be careful to align the gas line flairs and fittings properly, and firmly tighten the two flair nuts in place. Hold the orifice with the wrench while tightening—also hold the fitting in the gas control with a wrench while tightening or removing.
- As always, check for leaks when repairs are complete. 55-60 inch pounds torque will not damage the threads but will normally be sufficient to prevent leaks.



How to Change Electric Selector Switch

- Remove control knob for 110V/ 12V selector switch.
- 2 Remove cover of electric box by removing two Phillips-head screws from the top of the cover and sliding it off
- Remove the electric control box by removing the two Phillips screws from either side of the electric switch
- 4 Pull control rod off of switch
- Remove all wires from selector switch
- From the front of the electric box remove the two mounting screws and remove the electric selector switch.
- Place the new electric switch in place and mount with mounting screws.
- 8 Reconnect all wiring per proper wiring diagram
- Reposition the selector rod on the electric switch and align rod in front hole while pushing electric box back into position. Mount with the two Phillips-head screws.

Remember to attach the 115V ground wire to the casing

- 10. Attach cover with two screws.
- 11. Reinstall selector rod knob.

How to Change a Sourdillon Control Assembly

Refer to pages 27 and 28 for helpful illustrations

- Remove the *Innovator* from the built-in opening to give complete access to the unit
- Free the thermostat sensing tube from the secondary evaporator by first removing the evaporator grille, then backing out the tube retainer screws and pulling the tube loose.
- 3 Pull the sensing tube through the back of the unit and carefully coil in 3 to 4 inch diameter loops to avoid kinking or rupturing the tube

Sensing tube is not a in the field replacement item.

If the tube is damaged by mishandling, other parts (thermocouple igniter, gas inlet, pressure tap, etc.) may be salvaged and the control scrapped

- 4 Remove control knobs.
- 5 Remove the two 1/2" sheet metal burner box cover screws and slide off the burner box cover
- Remove the two 1/2" machine bolts (slotted or hex) to free the burner box from the flue tube assembly.
- 7 Pull the two white thermostat wires on the control (spade connectors) and the blue wire from the flame meter to the thermocouple interrupter. Also disconnect the igniter wire from the igniter electrode.
- Loosen the control mounting bracket by removing the 3 or 4 sheet metal screws holding it in place.
- 9. Carefully pull the bracket and control straight back.

NOTE: The microswitch forminals on the inside rear of the bracket may catch on the sheet metal base sfot a sudden pull will break the microswitch and nocessitate replacement.

Be careful!

- 10. Back the control out of the unit. Both the thermostat and gas/ electric switch control rods, springs and retainers may remain on the control If they do not, retrieve them with a coat hanger wire
- 11 Exchange the control mounting bracket Four Phillips-head screws hold the bracket to the control When replacing on the new control, be careful not to strip the threads in the aluminum valve body
- 12 Exchange the burner bracket. Two sheet metal screws hold the burner to the bracket. Firmly tighten screws to new burner for proper flame alignment.
- 13 Push control rods, springs and retainers about 75% of the way into the rod slots. Allow enough room to replace them on the control assembly as you push it back into place. This becomes easier with a second person helping at the front of the unit.
- 14. Replace the three or four sheet metal screws which hold the control mounting bracket in place. One of these screws must hold the green ground wire from the flame meter.
- Replace blue wire from the flame meter to the thermocouple interrupter spade connector and two white thermostat wires. Also replace igniter wire to igniter electrode.
- Remount burner bracket to flue tube assembly and replace burner box cover.
- 17. Replace control knobs.
- Carefully uncoil sensing tube. Push through back of cabinet and reinstall on secondary evaporator.
- 19 Replace *Innovator* into built-in opening.

How to Change a Lamp Switch

Refer to illustrations on page 27 for component locations

1 Follow Steps 1 through 10 on removal of Sourdillon Control Assembly, page 25. Omit Steps 2 and 3 but be careful not to damage the sensing tube as noted in Step 3. It is only necessary to pull the control far enough out to clear the control rods from the front panel

On 3-way units it is necessary to remove the electric control rods also. Remove the control rod knob first. Then remove the two Phillips-head screws from the electric box cover and remove cover Only the two Phillipshead screws inside the electric box need to be removed to remove the electric box assembly (If a separate screw is used for connecting the 110V ground it needs to be removed also). Pull the box far enough out to remove the control rod

- 2. Remove main door.
- 3 Remove hinge pin from control box as well as plastic cap in opposite hinge pin hole
- 4. Remove plastic end caps from control box

NOTE: On some Innovators, a screw was placed up from the bottom of the control box to socure the end cap. This must he removed to remove the end caps.

- 5. Remove control box cover by sliding it out to one side
- 6. Remove operating instructions decal by peeling off from one corner.
- 7. Pull the flame meter out and disconnect the blue and green wires from the terminals.
- Slide the control box panel from the control box.

- Disconnect the two black wires from the light switch terminals.
- 10 Carefully drill the pop rivets out from the top of the control box and free the light switch from the mounting holes
- 11 Place the new light switch in position and pop rivet in place Be sure to use washers on the bottom side of the switch to be sure it is held securely.
- 12 Reconnect the black wires to the light switch terminals
- 13. Slide the control box panel back in place. Note that this part must go in first slot closest to the unit so that the sliding cover may go in the second slot
- 14 Reconnect the flame meter, being careful to get the correct polarity (green - positive and blue — negative).
- 15. Reposition the flame meter in the slot on the control panel and carefully position the decal in the proper place


- 16 Replace the sliding cover and end caps Also replace the hir pin and plug.
- Follow Steps 13 through 17 "How to Change a Sourdil 🗷 Burner 1


On 3-way units, it is necessary to replace the electric box an control rod. Start by replacing the control rod assembly into: hole provided. Connect to switch to the control rod ET slide this assembly up to cabinet back Note that control rod must be aligned properly in front of the unit Replace the two Phillips-heat screws into the electric box # secure it to the cabinet back.


NOTE

Don't forget to reconnect the 115V ground wire to the metal casing. Replace the electric box cover and control rod knob


- 18 Replace main door.
- 19. Replace Innovator into builtid opening.








CONTROL SCHEMATIC and PARTS LIST for ALL INNOVATORS









FIGURE 22 — **BURNER BOX ASSEMBLY**

SOURDILLON CONTROL and BURNER ILLUSTRATIONS

Thermocouple



Can the Innovator Operate Without a 12 Volt Power Supply?

The answer is YES!

Simply slide open the burner observation port and apply a lighted match or your Instamatic Magiclick 2000 to the burner.

Your helper can depress the Gas/Electric selector and make sure gas is flowing to the burner. As soon as the flame meter moves to the right, he (your helper) can release the selector and the magnetic safety will take over


The only inconvenience you will experience is, of course, the lack of interior lighting without the 12 volt power supply. Otherwise the *Innovator* should operate normally


Call- out		M M	136
. #	Part #	Description 40 60	70
F.B.	3-320802	Door Trim Assembly •	٠
2	3-320713	Freezer Door Complete	
2	3-20823-001	Freezer Door Complete	•
2		Freezer Door Complete	-
3	5-330829	Body Liner	
	5-330708	Bodý Liner •	
	5-330816	Body Liner	. • (
4	3-320773	Butter Box Assembly •	
5	3-330776	Egg Tray	-
-			
6	3-330720	Bottom Body-Shelf	
7	3-330719	Center Body Shelf •	-
	3-330718	Top Body Shelf • •	1
9	3-330817	Top Body Shelf	• -
10	3-330786	Drip Tray	<u> }</u> • • •
11	3-330897	Evaporator Grille	, • ·
11	3-330892	Evaporator Grille •	ž E
12	2-330766	Travel Lock •	⁴ • 1
14	2-330805	Lamp Cover • •	
15	3-320794	Lamp Base Assembly • •	
16	2-330821	Center Hinge	•
17	1-330230	Hinge Pin Center, Bottom	÷ 1
18	1-330553	G/E Name Plate	£ .
19	2-330818	Cabinet Molding Center	10
20	3-330832	Cabinet Molding—L H	F
20	4-330723	Cabinet Molding L. H.	
20	4-330819	Cabinet Molding—L. H.	13
20	3-330877	Cabinet Molding—L. H.	n de
21-	3-330721	2	Š.
-			3
22	3-330780	End Cáp—Tổp, L. H.	, St.
	1-330779	Hinge Pin-Top • •	9.7 3.0
24	4-330725	Top Cap Extrusion ●	_a_
26	3-330781	End Cap—Top, R. H.	400
29	2-330749	Auto Ignition Assembly • •	***
30	3-340731	Electrical Box Cover • •	n in \bullet
31		Terminal Block 110V—2 prong	3
31_		Terminal Block 110V 4 Prong	in the
32	4-330743-001	Sourdillon Gas Control Assy.	
		(red stripe)	A. K.
32	4-330743-002	Sourdillon Gas Control Assy (blue stripe)	v.
- 32	4-330743-002	Sourdillon Gas Control Assy	42,7
- JZ	4-550/45-002	(green stripe)	73
33	3-320747	Electrical Box Assembly (110V)	
33	3-320728	Electrical Box Assembly (12V)	•
34	3-320736	Burner Bracket Cover Assembly • •	
35	3-320754	Selector Rod Assembly T/W (blue) • •	Arthur and a second
36	3-320758	G/E Control Rod Assembly (red) •	***
37	3-320750	Thermostat Control Rod Assy • •	
3/	J-320130	(yellow)	2
38	4-340845	Rear Support Plate	
* =====================================	\$ \(\frac{1}{2}\) \(\frac{1}{2		1 4 A

-			
	FIGURE 23		
AN.			
-			
}			
*			
~			
-			
1			
1 4 4			_ (e)
- 3.0			
8 % T-4		(2) (2)	
~ ~ ~	6	()	
1	0		
~	Y		
-			
2 *			
Ϋ \ -			
		$\lambda \in \mathcal{N}$	
	λ	$X = X \times X$	*
16		$\lambda = i + \lambda + i$	
		TX	
THE STATE OF THE S			
			Ž

Call Description 3-330831 41 Cabinet Molding-R. H. 3-330724 Cabinet Molding-R H. 41 4-330820 Cabinet Molding-R. H. 3-330878 Cabinet Molding-R. H 42 3-330722 Cabinet Molding—Bottom 43 4-330727 Control Panel 44 2-330762 Slide Plate, Control Panel 45 3-330763 End Cap, Bottom-R. H. 46 2-330761 Knob 47 4-330726 Control Box Assembly, Extrusion 48 3-330764 End Cap-Bottom, L. H. 50 3-330785-002 Vegetable Tray w/Cover, Small 51 3-330784-001 Vegetable Tray w/Cover, Large 3-330777 Door Shelf, Small 3-330778 Door Shelf, Bottom 3-320802 Decoration Trim-Name 3-320799 Decoration Trim—Lower 3-320853 Main Door Complete 0 3-320767 Main Door Complete 0 59 2-330757 Flame Indicator 0 3-330803 Wiring Diagram Decal (110V) 3-330702 Wiring Diagram Decal (12V) 64 1-330138 Warning Label 2-320791 Freezer Hinge Assembly, L. H ٠ 2-320790 Freezer Hinge Assembly, R. H. 3-330804 Lamp Bulb 3-330796 Lamp Switch 2-330740 Plastic Shelf Edge Retainer 1-330741 Wire Shelf Edge Collapsible 1-030063-003 Cap Plug 1-330337 Ice Cube Bucket 2-330363 Plastic Ice Tray (Petite) • 2-330679 Plastic Ice Tray 0 3-330765 Hole Plug 0 0 4-330772-001 Door Gasket 4-330772-002 Door Gasket 4-330772-003 Freezer Door Gasket 4-330772-004 Freezer Door Gasket 3-330787 **Butter Tray** 1-330702 Plastic Door Cap 3-330842 In-Line Fuse Holder 3-340733 Burner Bracket 2-330745 Ignition Switch 2-330749-002 Ignition Wire 2-330730 T/W Switch Less Wires 2-330848 Control Decal (110V) 2-330793 Gontrol Decal (12V)

Not shown in illustration. See following illustration—Figure 24 page 32





Schematic of entire control assembly from front panel knobs to . . . final assembly!





FIGURE 24

PARTS COMMON TO ALL INNOVATORS








FIGURE 26 — 3-WAY WIRING DIAGRAM (single element)

FIGURE 27 — ALTERNATE 3-WAY WIRING DIAGRAM (single element) for separate heating element and igniter/lamp circuits





3-WAY WIRING DIAGRAM (double element)

:

:

FIGURE 29—
ALTERNATE 3-WAY WIRING DIAGRAM
(double element)
for separate heating element and igniter/lamp circuits

Heating Element in Gas/Electric Refrigerators




FIGURE 32—
DOUBLE ELEMENT

On the gas/electric operated refrigerators, heat is supplied by an electric element (A) mounted on the cooling unit inside the insulated cover (B)—removed for illustration purposes. See Fig. 30, 31, and 32.

The element is accessible for replacement after removal of insulated cover and the rockwool insulation.


- Check that the size and wattage of the heater are correct for the unit Heater should fit snugly to provide proper heat transfer.
- Check that the supply voltage corresponds to the voltage stamped on the heating element
- 3. Make sure the heater is inserted at the bottom of the well pocket.

CAMPING FREEZE (TH) BOILER BOX

 Be careful placing the insulation in its proper position again after replacement.

a de la companya note de la companya de la companya

The edges of the opening in the cover may be sharp! Be careful!




Vire terminals to be 250 x .032 nsulation support receptacles.


All elements must meet U.L. requirement 1030


vire terminals to be 250 x .032 sulation support receptacles.


All elements must meet U.L requirement 1030



WIRING DIAGRAM Heating element for IM-62 C Part #330-238 - 120v — red (18 ga.) 240 watts Common - white (18 ga.) 15.88 814 not to scale max NOTE: Each element is supplied with Consul cooling unit nickel alloy with 6 9.69 asbestos/teflon ins of insulation sleeves Wire terminals to be .250 x .032 insulation support receptacles All elements must meet U.L. requirement 1030









Wire terminals to be .250 x .032 insulation support receptacles


All elements must meet U.L. requirement 1030







Vire terminals to be .250 x .032 nsulation support receptacles

All elements must meet U.L. requirement 1030



All elements must meet U.L. requirement 1030







All elements must meet U.L. requirement 1030

All elements must meet U.L. requirement 1030

insulation support receptacles

insulation support receptacles





Innovator Operation Analysis for Gas

WARNING: Tampering with cooling unit will void warranty . . . CONTENTS HIGHLY FLAMMABLE AND TOXIC.

MAY - THE WASHING MALTON

	SYM	MPTOM		CAUSE	
Refrigerator too cold	Refrigerator not cold enough Lack of refrigeration	Frost forms rapidly Burner flame goes out	Odor inside cabinet Odor outside cabinet	NOTE: It will be noted in this tabulation that several causes can be responsible for the one effect. The real cause or causes should be determined by a process of elimination, investigating each possible cause, proceeding to the bottom.	
	The state of the s		•	Gas leaks pages 5, 11	
	• •		. #	Inadequate ventilation pages 8, 10	
	•			Unit not level page 8	
	•			Orifice clogged (Replace) page 23	
				Thermocouple tip improperly located pages 11, 13, 23	
				Improper contact between thermocouple and safety control magnet	
		•	- TE L	Faulty safety control magnet (replace control) page 25	
				Improper maximum flame pages 12, 20	
				By-pass flame too small page 11	
•				By-pass flame too large page 20	
	• •	Terran P		Improper position of the flue bafflefigure 21, page 13	
	•			Unstable burner flame pages 8, 11	
				Improper food storage page 10	
		######################################		Improper storage of liquid and moist foods page 10	
	•			Leaky door gaskets page 10	
	• •	• 21-1		Obstructed flue pages 11, 12	
				Burner mis-alignment with flue tube page 13	
A STATE		Company of the state of the sta		Insufficient primary air (see "Installation")pages 5, 6, 7	
			• 145 178 189 189	Infrequent cleaning of food compartment page 10	
74.1			•.	Refrigerator shut off with closed door page 10	
		The Control of the Co	•	Unwrapped odorous food page 10	
•		1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2		Incomplete contact of thermostat tube page 11	
	• •			Lost thermostat charge page 11	
	• 10			Defective cooling unit (Refer to "Things to Do") page 47	
•			The state of the s	Room temperature too low page 3	

Innovator Operation Analysis for Electric

WARNING: Tampering with cooling unit will void warranty . . . CONTENTS HIGHLY FLAMMABLE AND TOXIC.

SYMPTOM CAUSE enongh NOTE: It will be noted in this tabultion that several causes Refrigerator not cold Refrigerator too cold can be responsible for one effect. The real cause or causes Lack of refrigeration Odor inside cabinet Frost forms rapidly should be determined by a process of elimination, investigating each possible cause, starting at the top of the tabulation and proceeding to the bottom. Inadequate ventilationpages 8, 9, 10 Refrigerating unit not level Heater faulty, wrong voltage or type pages 39-44 Inconsistent voltage (under "Tips on Cooling Unit Analysis) page 8 Electric connections loose (under "Trouble Shooting Chart") page 24 Element not inserted correctly in its pocket page 38 Improper food storage page 10 Improper storage of liquids and moist foods page 10 Leaky door gaskets page 10 Infrequent cleaning of food compartment page 10 Unwrapped odorous food page 10 Incomplete contact of sensing tube page 22 Lost thermostat charge page 11

Defective cooling unit (see "Things to Do") page 47

Room temperature too low page 3

Manual provided courtesy Bryant RV Services www.bryantrv.com

All manuals are believed to be released for distribution, and/or in the public domain.

Service manuals provided with the understanding that persons using them are well versed in proper safety practices, and are familiar with basic safety procedures, including, but not limited to safety procedures dealing with 120 volt electricity, high amperage 12 volt circuits an LPG (propane) systems.

If in doubt, consult a professional (better safe than sorry).